

Active Power Control in Wind Parks

SIEMENS

**Siemens Wind
Turbines - Americas**



© Siemens AG 2011. All rights reserved.

Copyright © Siemens Energy, Inc. 2011. All rights reserved.

What Are Common Active Power Control Requirements **SIEMENS** in the US?

Existing:

- Power Output (Curtailment) Control
- Ramp Rate Control
 - Curtailments
 - Start-up
- Regulation Up for Underfrequency
 - Adjustable Droop
- Regulation Down for Overfrequency
 - Adjustable Droop
- High Wind Shutdown
- Rate Variation Control



© Siemens AG 2011. All rights reserved.

Expectation for New Requirements

Expected in the next 5 years:


- Automatic Generation Control (AGC) participation
- Spinning Reserve (“Delta” Control)
 - Frequency Responsive
 - Remote
- Transient Underfrequency (“Inertial”) Response



Type 4 Variable Speed Full Converter WTG

Basic operation – typical configuration

SIEMENS




- Rotor drives gearbox in geared systems. Gearbox eliminated in DD (direct drive); rotor directly drives low-speed, multi-pole generator
- Generator converts mechanical power to AC electric power. Generator can be asynchronous, permanent magnet or synchronous for geared system, pm or synchronous for DD.
- Generator-side converter converts AC electric power to DC
- Line-side converter converts DC to system-frequency AC (50 Hz or 60 Hz, as appropriate) and provides voltage regulation capability
- Can control real and reactive power output from line-side converter – rapid, precise control.

Ramp Rate Control - Smooth, Controlled Transition from One Output Level to Another



Some ISOs (e.g., ERCOT, some Canadian provinces) require ramp rate control to smoothly transition from one output level to another during curtailments.

- Can select any ramp rate slower than ~10%/sec, assuming availability of adequate wind power
- Typical ramp requirement is 10% per minute or slower.




Frequency Droop Control

Some ISO/RTOs require the use of frequency droop response from wind parks

- Normally constant (5%) frequency droop (5% change in freq → 100% change in output), but variable droop sometimes required (e.g., larger droop for small frequency excursions, smaller droop for larger excursions).
- Both reg up (underfreq), assuming curtailed state, and reg down (overfrequency) required.
- Sometimes conflicts w/ curtailments, SPS operations.
- Controls compatible with ERCOT protocols.

Frequency Droop Response




Recent Field Test Results – Regulation Down Demonstrating Frequency Regulation for Overfrequency

SIEMENS

Recent results from test of “frequency control sensitive mode” (proportional droop response) – required by UK grid

Turbines at reference power Fast frequency increase Increase in turbine output power




Fast frequency recovery

Recent Field Test Results – Regulation Up Demonstrating Frequency Regulation for Underfrequency

SIEMENS


Recent results from test of “frequency control sensitive mode” (proportional droop response) – required by UK grid



High Wind Shutdown – What is it?

Ramp-down of power in anticipation of high-wind speed trip.

Reduces power loss and resulting frequency reduction caused by weather fronts.




Rate Variation Control

Control of output power change, e.g., “no more than 10% change per minute”

Since electric power varies as cube of wind speed, rate variation control requires operation at reduced output power levels during conditions when wind speed varies or use of energy storage.

Controls typically assume persistence and use recent history to set output.

Seldom used.




Delta Control – Operate with a Constant Delta Below Maximum Output



Some ISOs are considering the use of wind for regulation up and spinning reserve duty at some times of the day to release fossil capacity.

- Requires “spilling wind,” but may be the least expensive way to provide capability
- Can select any delta (MW) assuming availability of adequate wind power



Transient Under-Frequency Response ("inertial response")

Rapid injection of energy required after sudden frequency drop – useful to forestall load shedding and generator tripping, especially on island systems.


Sometimes called "inertial response" because synchronous generators provide this energy from shaft KE.

Converter-controlled WTGs do not provide this function naturally, but can be programmed to provide it.

Wind turbines have substantial inertia in rotor – could be exercised to provide a short-term power boost. Energy storage could be used, too.

Under development and testing.

Preliminary simulations for 20% wind case with different transient controls













Automatic Generation Control (AGC) – What is it?

- Slow control (30 sec typical); small adjustments to maintain Area Control Error (including tie line flows) within limits.
- Can be used to supplement P-command from Park RTU.
- No clear reason to include separately in wind park controls, since wind parks are capable of very fast response (few sec for typical output response, if no ramp rate restrictions are imposed).

Summary – How Siemens WTGs provide Power Control **SIEMENS**

(existing and anticipated)

<i>Capability</i>	<i>Now</i>	<i>Soon</i>
Power Output (Curtailment) Control		
Ramp-Rate Control (ref change and startup)		
Frequency Droop Regulation Up		
Frequency Droop Regulation Down		
Frequency-Dependent Droop		
Spinning reserve (“delta control”) capability		
Transient underfrequency (“inertial”) response		
High wind shutdown		
AGC Response (from Park RTU)		
Rate Variation Control		

SIEMENS

Questions?



Thank You!

© Siemens AG 2010. All rights reserved.